VibeLab[™] VL-145 Series


DIGITAL VIBRATION CONTROLLERS


145x - Sine and Random

145s - Sine

145r - Random

- Straightforward Virtual Instrument operating under Windows[™].
- Automatic spectral calculation of Acceleration, Velocity and Displacement.
- Programmed test requirements automatically compared to system capabilities.
- Online help for both novice and experienced users.
- Generate reports to use with your preferred software.
- Fully expandable to the top of the line VibeLab[™] controller.
- Comes completely assembled with everything you need including computer, monitor, keyboard and accelerometer with built-in signal conditioning. Not a kit.





Complete Controller System Includes:

Computer, Monitor, Keyboard, Mouse
VibeLab ™ and Windows™ software installed, ready to run
Printer

VibeLab ™ Shaker interface PC Board w/accelerometer power supply, factory installed

Accelerometer package: accelerometer, cable, stud, and mounting base



Labworks Inc.

VibeLab[™] VL-145 Series

Digital Vibration Controllers



2950 airway ave.

a-16, costa mesa, ca 92626 (714) 549-1981 www.labworks-inc.com fax (714) 549-8041

General Description

The VL-145 series VibeLab controllers are pc-based (WindowsTM) vibration test controllers. These controllers generate an analog output signal suitable for input to a vibration test system amplifier in response to specific user-defined test parameters. Vibration acceleration feedback from an accelerometer mounted on the shaker, fixture, and/or test article is compared with the desired test levels and the controllers internal servo adjusts its output to produce the corresponding vibration at the accelerometers location.

The VL-145 virtual instrument user interface layout, with its use of minimal hidden menus and straight forward terminology, is easy to use and the intuitive layout reduces the time required to learn, program, and run specific tests. Most critical system functions are automatically cross-checked during the program phase against the vibration system capabilities, accelerometer sensitivities, etc. to prevent erroneous or harmful tests. Previously defined test profiles can be recalled and saved at will as well as defined as the default start-up profile.

Three versions of the VL-145 single channel controller are available. The VL-145x single channel sine and random controller, VL-145s single channel sine only vibration and the VL-145r single channel random only vibration controller. The controller can be configured to monitor the operating level of the vibration test system and can be programmed to shut the system down if maximum operating levels are exceeded. The system parameters can be recalled from the complete Labworks system library or entered and saved to suit the your vibration system limitations.

VibeLab's primary report output is graphical. Either a single large or two smaller graphs can be prepared and printed or copied to the clipboard for use with other WindowsTM-based applications. Data files saved are spreadsheet compatible for custom report generation. The chronological test log is also available for direct printing or inclusion in custom reports.

General Specifications

Model Configuration*

VL-145x VL-145s VL-145r

Frequency Range

Random' Sine³ Display Units

Reports

Signal Input

Number of Input Channels Acceleration Range

Acceleration Resolution Maximum Input Voltage Connectors Dynamic Range

Vibration System Protection

System Checker

Sensitivity Checker

Run-Time and **Output Level Monitors**

Test Article Protection

Acceleration Random*

Sine*

Manual Abort

External Interlock

Sine and random Sine only Random only

6 to 2,000 Hz or 2 to 500 Hz 2 to 10.000 Hz

English or metric units with automatic conversion

Graphical, tabular, current, or post analysis

Random: 0.2 to 100 grms* Sine: 0.1 to 200 gpk* 16 Bit

5 V peak BNC

80 dB minimum

Automatic cross check of program with the vibration system force and displacement capabilities Automatic cross check of

program with accelerometer dynamic range and sensitivity Show the vibration system operating level and VibeLab signal output voltage level

Open loop/low gain + rate detection Over and/or under acceleration alarm and abort levels System operation level, acceleration and displacement Red "STOP" key and external shutdown terminals

Normally open switch or Logic Low

Training

Run Modes Random*

Sine*

Program

Random Spectrum Entry*

Sine Sweep Profile Entry*

Other Parameters

Test

Save and Recall

Last Test

Run Time Display

Graphical Data

System Monitor

Timers

Graph/Data Save and Print

Post Analysis

Demonstration/Learning mode

Manual, timed, timed cycle, external switch/TTL

Manual, timed, sweep cycle, external switch/TTL

Break point or line segment slope, graphical display

Break point or constant level, graphical display of acceleration, velocity, displacement, and frequency

Virtual intrument design, minimum hidden menus

All parameters, user named including all program parameters, data, and display settings

The last test run is automatically saved and can be recalled and continued or analyzed

Single or dual graphs with acceleration or output drive data: Ch 1, Control, Drive

Vibration system operation level meter

Cycle timers* and sweep cycle counter*

Save a full data set to disk, print direct, or clipboard the Test Log or any Graph

Any saved test can be recalled and the data re-configured for report printing or saving to the clipboard for incorporation into other Windows applications

^{*}Sine specifications apply only to the VL-145x and VL-145s.

^{*}Random specifications apply only to the VL-145x and VL-145r.